



RG520x&RM520N Series

eSIM LPA Application Note

5G Module Series

Version: 1.0

Date: 2022-09-21

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>.

Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an "as available" basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2022. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
-	2021-04-22	Remy SHI/ Ryker ZHANG	Creation of the document
1.0	2022-09-21	Ryker ZHANG	First official release

Contents

About the Document	3
Contents	4
Table Index.....	5
Figure Index	6
1 Introduction	7
1.1. Applicable Modules	7
2 eSIM LPA AT Commands.....	8
2.1. AT Command Introduction	8
2.1.1. Definitions.....	8
2.1.2. AT Command Syntax	8
2.2. Declaration of AT Command Examples	9
2.3. Description of AT Commands	9
2.3.1. AT+QESIM Query eSIM LPA Settings.....	9
2.3.2. AT+QESIM="ipa_enable" Enable/Disable eSIM LPA	10
2.3.3. AT+QESIM="profile_brief" Query the Number of Profiles.....	11
2.3.4. AT+QESIM="profile_detail" Query Detailed Information of Profiles.....	11
2.3.5. AT+QESIM="eid" Query eSIM ID	12
2.3.6. AT+QESIM="delete_profile" Delete a Profile	13
2.3.7. AT+QESIM="nickname" Configure a Profile Nickname	14
2.3.8. AT+QESIM="def_svr_addr" Update Default SM-DP Server Address.....	15
2.3.9. AT+QESIM="enable_profile" Enable a Profile	16
2.3.10. AT+QESIM="disable_profile" Disable a Profile	17
3 Add a Profile	18
3.1. Install Drivers	18
3.2. Install Development Software	18
3.3. Install SSL Certificate (Optional).....	18
3.4. Compile Source Code	19
3.5. Confirm eSIM LPA Configuration	19
3.6. Install the Profile.....	20
3.7. Check the Profile.....	20
4 Common Errors.....	21
5 Appendix Reference	22

Table Index

Table 1: Applicable Modules.....	7
Table 2: Types of AT Commands	8
Table 3: Development Software	18
Table 4: Directory Structure of Linux eSIM LPAd Source Code	19
Table 5: Terms and Abbreviations	22

Figure Index

Figure 1: Prompt of Successful Installation	20
Figure 2: Prompt of Failed Installation	20

1 Introduction

The embedded SIM (also called eSIM or eUICC, referred to as eSIM hereinafter) card is a new secure element designed to remotely manage multiple mobile network operator subscriptions and be compliant with GSMA specifications. Available in various form factors, either plugged-in or soldered, the eSIM is easy to integrate in any kind of device.

LPA (Local Profile Assistant) is able to download the encrypted profile to eSIM, and also provides end users with a local management interface so that they can manage profile on eSIM.

This document mainly introduces the eSIM profile related AT commands, how to add a profile and common errors for installation of the profile.

1.1. Applicable Modules

Table 1: Applicable Modules

Module Series	Module
RG520x	RG520N Series
	RG520F Series
RM520N	RM520N-GL

2 eSIM LPA AT Commands

2.1. AT Command Introduction

2.1.1. Definitions

- <CR> Carriage return character.
- <LF> Line feed character.
- <...> Parameter name. Angle brackets do not appear on the command line.
- [...] Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on the command line. When an optional parameter is not given in a command, the new value equals its previous value or the default settings, unless otherwise specified.
- Underline Default setting of a parameter.

2.1.2. AT Command Syntax

All command lines must start with **AT** or **at** and end with **<CR>**. Information responses and result codes always start and end with a carriage return character and a line feed character: **<CR><LF><response><CR><LF>**. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and **<CR>** and **<LF>** are deliberately omitted.

Table 2: Types of AT Commands

Command Type	Syntax	Description
Test Command	AT+<cmd>=?	Test the existence of the corresponding command and return information about the type, value, or range of its parameter.
Read Command	AT+<cmd>?	Check the current parameter value of the corresponding command.
Write Command	AT+<cmd>=<p1>[,<p2>[,<p3>[...]]]	Set user-definable parameter value.
Execution Command	AT+<cmd>	Return a specific information parameter or perform a specific action.

2.2. Declaration of AT Command Examples

The AT command examples in this document are provided to help you learn about the use of the AT commands introduced herein. The examples, however, should not be taken as Quectel's recommendations or suggestions about how to design a program flow or what status to set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean that there is a correlation among these examples, or that they should be executed in a given sequence.

2.3. Description of AT Commands

2.3.1. AT+QESIM Query eSIM LPA Settings

This command queries the eSIM LPA settings.

AT+QESIM Query eSIM LPA Settings	
Test Command	Response
AT+QESIM=?	 +QESIM: "ipa_enable", (list of supported <enable>s) +QESIM: "profile_brief" +QESIM: "profile_detail", (range of supported <profile_ID>s) +QESIM: "eid" +QESIM: "delete_profile", (range of supported <profile_ID>s) +QESIM: "nickname", (range of supported <profile_ID>s), <nickname> +QESIM: "def_svr_addr", <address> +QESIM: "disable_profile", (range of supported <profile_ID>s) +QESIM: "enable_profile", (range of supported <profile_ID>s)
	OK
Maximum Response Time	300 ms
Characteristics	/

2.3.2. AT+QESIM="Ipa_enable" Enable/Disable eSIM LPA

This command enables or disables the eSIM LPA.

AT+QESIM="Ipa_enable" Enable/Disable eSIM LPA	
Write Command	Response
AT+QESIM="Ipa_enable"[,<enable>]	If the optional parameter is omitted, query the current setting: +QESIM: "Ipa_enable",<enable>
	OK
	If the optional parameter is specified, enable/disable the eSIM LPA: OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<enable>	Integer type. Enable or disable the eSIM LPA.
<u>0</u>	Disable
<u>1</u>	Enable

NOTE

If the eSIM LPA is disabled, **ERROR** is returned after the execution of other commands.

Example

```
AT+QESIM="Ipa_enable"          //Query the currently configuration.
+QESIM: "Ipa_enable",0

OK
AT+QESIM="Ipa_enable",1        //Enable eSIM LPA.
OK
AT+QESIM="Ipa_enable"          //Query the current settings.
+QESIM: "Ipa_enable",1

OK
```

2.3.3. AT+QESIM="profile_brief" Query the Number of Profiles

This command queries the number of profiles in eSIM.

AT+QESIM="profile_brief" Query the Number of Profiles

Write Command	Response
AT+QESIM="profile_brief"	+QESIM: "profile_brief",<profile_number>
	OK
	Or
	ERROR
Maximum Response Time	300 ms
Characteristics	/

Parameter

<profile_number> Integer type. The number of profiles. Range: 1–8.

Example

AT+QESIM="profile_brief" //Query the number of profiles.

+QESIM: "profile_brief",4

OK

2.3.4. AT+QESIM="profile_detail" Query Detailed Information of Profiles

This command queries the detailed information of profiles in eSIM.

AT+QESIM="profile_detail" Query Detailed Information of Profiles

Write Command	Response
AT+QESIM="profile_detail",<profile_ID>	+QESIM: "profile_detail",<ICCID>,<state>,<nickname>,<SPN>,<name>,<class>
>	OK
	Or
	ERROR
Maximum Response Time	300 ms
Characteristics	/

Parameter

<profile_ID>	Integer type. Profile ID.
1	Profile 1
2	Profile 2
3	Profile 3
4	Profile 4
5	Profile 5
6	Profile 6
7	Profile 7
8	Profile 8
<ICCID>	String without double quotes. ICCID (Integrated Circuit Card Identifier) number of the eSIM.
<state>	Integer type. The state of profile.
0	Inactive
1	Active
<nickname>	String type. The nickname of profile.
<SPN>	String type. The service provider name of profile.
<name>	String type. The name of profile.
<class>	Integer type. The type of profile.
0	Test profile
1	Provisioning profile
2	Operational profile

Example

```
AT+QESIM="profile_detail",1      //Query the detailed information of profile 1.
+QESIM: "profile_detail",8988247000111763810F,0,"Profile1","Transatel","TSL_0131",2
OK
```

2.3.5. AT+QESIM="eid" Query eSIM ID

This command queries the eSIM ID.

AT+QESIM="eid" Query eSIM ID	
Write Command	Response
AT+QESIM="eid"	+QESIM: "eid",<eSIM_ID>
	OK Or ERROR
Maximum Response Time	300 ms

Characteristics

/

Parameter

<eSIM_ID> String without double quotes. The eSIM ID.

Example

```
AT+QESIM="eid"      //Query the eSIM ID.  
+QESIM: "eid",89033023424310000000001251649628  
OK
```

2.3.6. AT+QESIM="delete_profile" Delete a Profile

This command deletes the profile with a specific profile ID. You can execute this command to delete the profile only after the profile is disabled by **AT+QESIM="disable_profile"**.

AT+QESIM="delete_profile" Delete a Profile

Write Command	Response
AT+QESIM="delete_profile",<profile_I D>	OK Or ERROR
Maximum Response Time	300 ms
Characteristics	/

Parameter

<profile_ID> Integer type. Profile ID.

- 1 Profile 1
- 2 Profile 2
- 3 Profile 3
- 4 Profile 4
- 5 Profile 5
- 6 Profile 6
- 7 Profile 7
- 8 Profile 8

Example

```
AT+QESIM="profile_brief"      //Query the number of profiles.  
+QESIM: "profile_brief",4  
  
OK  
AT+QESIM="delete_profile",2   //Delete profile 2  
OK  
AT+QESIM="profile_brief"      //Query the number of profiles.  
+QESIM: "profile_brief",3  
  
OK
```

2.3.7. AT+QESIM="nickname" Configure a Profile Nickname

This command configures the nickname of the profile with a specific profile ID.

AT+QESIM="nickname" Configure a Profile Nickname

Write Command	Response
AT+QESIM="nickname",<profile_ID>,<nickname>	OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<profile_ID> Integer type. Profile ID.

- 1 Profile 1
- 2 Profile 2
- 3 Profile 3
- 4 Profile 4
- 5 Profile 5
- 6 Profile 6
- 7 Profile 7
- 8 Profile 8

<nickname> String type. The nickname of profile.

Example

```
AT+QESIM="nickname",3,"Quectel"      //Configure the nickname of profile 3.
OK
AT+QESIM="profile_detail",3          //Query the detailed information of profile 3.
+QESIM: "profile_detail",8988247000111761996F,0,"Quectel","Transatel","TSL_0131",2

OK
```

2.3.8. AT+QESIM="def_svr_addr" Update Default SM-DP Server Address

This command updates the default SM-DP server address.

AT+QESIM="def_svr_addr" Update Default SM-DP Server Address	
Write Command	Response
AT+QESIM="def_svr_addr"[,<address>]	If the optional parameter is omitted, query the current setting: +QESIM: "def_svr_addr",<address>
	OK
	If the optional parameter is specified, update the default SM-DP server address: OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<address> String type. The default SM-DP server address. No more than 255 characters in length.

Example

```
AT+QESIM="def_svr_addr","esim.wo.com.cn"      //Update the default SM-DP server address.
OK
AT+QESIM="def_svr_addr"                      //Query the current default SM-DP server address.
+QESIM: "def_svr_addr","esim.wo.com.cn"

OK
```

2.3.9. AT+QESIM="enable_profile" Enable a Profile

This command enables the profile with a specific profile ID.

AT+QESIM="enable_profile" Enable a Profile

Write Command	Response
AT+QESIM="enable",<profile_ID>	OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<profile_ID>	Integer type. Profile ID. 1 Profile 1 2 Profile 2 3 Profile 3 4 Profile 4 5 Profile 5 6 Profile 6 7 Profile 7 8 Profile 8
--------------	---

Example

```
AT+QESIM="enable_profile",2      //Enable profile 2.  
OK  
  
+CPIN: READY  
  
+QUSIM: 1  
  
+QIND: SMS DONE  
  
+QIND: PB DONE  
AT+QESIM="profile_detail",2      //Query the detailed information of profile 2.  
+QESIM: "profile_detail",89886970000000003873,1,"Profile2","GCKOEM","DummyProfile",2  
  
OK
```

2.3.10. AT+QESIM="disable_profile" Disable a Profile

This command disables the profile with a specific profile ID.

AT+QESIM="disable_profile" Disable a Profile	
Write Command AT+QESIM="disable_profile",<profile_ID>	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<profile_ID>	Integer type. Profile ID. 1 Profile 1 2 Profile 2 3 Profile 3 4 Profile 4 5 Profile 5 6 Profile 6 7 Profile 7 8 Profile 8
---------------------------	---

Example

```
AT+QESIM="disable_profile",2      //Disable profile 2.  
OK  
AT+QESIM="profile_detail",2      //Query the detailed information of profile 2.  
+QESIM: "profile_detail",89886970000000003873,0,"Profile2","GCKOEM","DummyProfile",2  
OK
```

3 Add a Profile

This chapter describes how to add profiles by eSIM LPA with the help of the eSIM LPAd software installed on your Linux PC.

3.1. Install Drivers

Install USB driver and QMI_WWAN driver on your Linux PC. Contact Quectel Technical Supports to assist in the installation of the drivers if necessary.

3.2. Install Development Software

You need to install the following software on your Linux PC for preparing the development environment.

Table 3: Development Software

Name	Version	Description
make	3.81 and above	Compile source code
cURL	7.34.0 and above	HTTP(S) communication
OpenSSL	1.0.1f and above	Verify SSL certificate

For example, you can execute the following command to install the above software under Ubuntu system:

```
sudo apt-get install make
sudo apt-get install libcurl4-openssl-dev
sudo apt-get install openssl
```

3.3. Install SSL Certificate (Optional)

If the eSIM profile provider has provided the SSL certificate, install it according to the following steps.

- Execute the following command in terminal window to install the certificate(s) under the directory of `/usr/local/share/ca-certificates/`:

```
sudo cp ~/GSMA.crt /usr/local/share/ca-certificates/
```

- Execute the following command to update the SSL certificate:

```
sudo update-ca-certificates
```

3.4. Compile Source Code

Table 4: Directory Structure of Linux eSIM LPAd Source Code

Storage Path of Source Code	Description
<code>./app</code>	Application code folder, containing <i>main.c</i>
<code>./common</code>	Common definition
<code>./http_manager</code>	HTTP application management
<code>/qmi_manager</code>	QMI application management
<code>./qmi_manager/legacy_qmi</code>	Quectel Linux QMI device driver
<code>./Makefile</code>	Compile configuration file

Enter the root directory of eSIM LPAd source code and execute the following command to compile the source code:

```
sudo make
```

After compilation is completed, an executable file named *quectel_ipad* will be generated in the root directory of eSIM LPAd source code.

3.5. Confirm eSIM LPA Configuration

Make sure that the eSIM LPA is enabled. If not, enable it through **AT+QESIM="ipa_enable",1**.

3.6. Install the Profile

Execute the following command in terminal window to run *quectel_ipad* to install the profile:

```
sudo ./quectel_ipad -A [activation_code]
```

You can obtain the activation code from the operator, and “\$” in the activation code must be replaced by “\\$”. For example:

```
sudo ./quectel_ipad -A 1\$esim.quectel.com\$0123456789ABCDEFGHIJKLMNOPQRSTUVWXYZ\$
```

Due to the blocking mechanism in *quectel_ipad*, there is no log output during the installation and do not terminate the program at the moment. Log information can be printed in terminal window if debugging is required.

When the installation succeeds or fails, the following prompt will appear respectively in terminal window:



Figure 1: Prompt of Successful Installation



Figure 2: Prompt of Failed Installation

3.7. Check the Profile

After installing the profile successfully, you can check the profile information through **AT+QESIM="profile_brief"** and **AT+QESIM="profile_detail",<profile_ID>**.

4 Common Errors

This chapter mainly introduces the common errors for installation of the profile.

● Network

Common errors about network can be analysed from the error prompt and error code of cURL in log printed in terminal window, as follows:

1. Error code 6: hostname can't be resolved.
2. Error code 35: SSL connect error.

Replace the network environment and try to download the profile again. Firewalls and network agents may affect the installation of profile.

● Server

Common errors are as follows:

1. HTTP service unavailable (service issues, you need to consult the service provider).
2. The eSIM ID you request is not the same as the one saved in the SM-DP server (activation code has been used, you need to change activation code or consult the provider).

● Module

Errors can be reported during the installation if one of the following situations appears.

1. There is a problem with the profile package returned by the server.
2. The same profile has already been installed in eSIM card.

The most common situation is that the same profile has already been installed in eSIM card. When you encounter the situation, check the profile that has been installed, which can be distinguished by ICCID through **AT+QESIM="profile_detail",<profile_ID>**.

5 Appendix Reference

Table 5: Terms and Abbreviations

Abbreviation	Description
eSIM	embedded Subscriber Identity Module
eUICC	embedded Universal Integrated Circuit Card
GSMA	Global System for Mobile Communications Association
HTTP	Hypertext Transfer Protocol
HTTPS	Hypertext Transfer Protocol Secure
ICCID	Integrated Circuit Card Identifier
ID	Identifier
LPA	Local Profile Assistant
SM-DP	Subscription Manager - Data Preparation
SSL	Secure Sockets Layer